

## Assembly Instruction For21265

- **1.**Turn the nipple into the coupler then secure by the hex nut.
- 2. Attach the cap on the nipple then secure by the loop.
- 3. Attach the nipple 1 into the metal sheet.
- 4. Attach the cap 1 on the nipple 1 then secure by the ball 1.
- 5. Attach the cap 2 on the nipple 2 then secure by the ball 2.
- 6. Attach the glass on the socket then secure by the socket ring.

