

## **Surface Mount Installation**

Step One




Using hands, separate outer aluminum shell from LED lamp.

Step Two



Using included hardware and a screw driver, secure outer aluminum shell to cabinet surface

Step Three



Feed connecting cord through a pre-drilled hole in the cabinet surface or through the cut-out of the outer aluminum shell.

Secure LED lamp into outer aluminum shell.

## Recessed Installation

Step One



Using hands, separate outer aluminum

shell from LED lamp.

Step Two



Cut out from the bottom of the cabinet a hole using a 2.5" hole saw.

Step Three



Feed connecting cord through the hole in cabinet and secure LED lamp.